



Wood Burning Heater Assembly Instructions



WB-1. To install the wood burning heater, get help to lift heater into the hole in the back of the sauna.



WB-2. Secure with provided lag screws.
** Do not overtighten as this will strip the screws.*



WB-3. Attach chimney elbow to the wood burning stove by pushing provided bolts into place and securing with nuts on the other side.



WB-4. Using a wrench to hold the nut on the inside, tighten the bolts completely with the drill or a wrench.



WB-5. Insert the flanged end of the chimney head onto the elbow firmly. ** Some finessing may be required.*
** Wash the rocks thoroughly before placing them into the heater.*



WB-6. Space rocks out evenly in top of heater.
** Operate the heater for an hour with the sauna door fully open to burn off any residual coating from the manufacturing process before using.*